

HT-T4

MAX

User Manual

10 Inch Electric Scooter

Contents

1. Riding Safety	01
2. Packing List	03
3. Diagram	04
4. Assembling Your Kick Scooter	05
5. First Ride	06
6. Charging	07
7. Learning to Ride	07
8. Warnings	09
9. Folding and Carrying	13
10. Maintenance	14
11. Parameters	15
12. Warranty	16

1 Riding Safety

1. The Kick Scooter is a recreational product. Before mastering riding skills, you need to practice. We are not responsible for any injuries or damage caused by a rider's inexperience or failure to follow the instructions in this document.
2. Please understand that you can reduce the risk by following all the instructions and warnings in this manual, but you cannot eliminate all the risks. Remember that whenever you ride the Kick Scooter you risk injury from loss of control, collisions, and falls. When entering into public spaces always comply with the local laws and regulations. As with other vehicles, faster speeds require longer braking distance. Sudden braking on low traction surfaces could lead to wheel slip, or falls. Be cautious and always keep a safe distance between you and other people or vehicles when riding. Be alert and slow down when entering unfamiliar areas.
3. Always wear a helmet when riding. Use an approved bicycle or skateboard helmet that fits properly with the chin strap in place, and provides protection for the back of your head.
4. Do not attempt your first ride in any area where you might encounter children, pedestrians, pets, vehicles, bicycles, or other obstacles and potential hazards.
5. Respect pedestrians by always yielding the right of way. Pass on the left whenever possible. When approaching a pedestrian from the front, stay to the right and slow down. Avoid startling pedestrians. When approaching from behind, announce yourself and slow down to walking speed when passing. Please obey local traffic laws and regulations if situation is different.
6. In places without laws comply with the safety guidelines outlined in this manual. We are not responsible for any property damage, personal injury/ death, accidents, or legal disputes caused by violations of the safety instructions.
7. Do not allow anyone to ride your Kick Scooter on his/her own unless they have carefully read this manual and followed the New Rider Tutorial in the App. The safety of new riders is your responsibility. Assist new riders until they are comfortable with the basic operation of the Kick Scooter. Make sure each new rider wears a helmet and other protective gear.
8. Before each ride check for loose fasteners and damaged components. If the Kick Scooter makes abnormal sounds or signals an alarm, immediately stop riding. Diagnose your Kick Scooter via the App and call your dealer/ distributor for service.

9. Be alert! Scan both far ahead and in front of your Kick Scooter - your eyes are your best tool for safely avoiding obstacles and low traction surfaces (including, but not limited to, wet ground, loose sand, loose gravel, and ice).
10. To reduce risk of injury, you must read and follow all "CAUTION" and "WARNING" notices in this document. Do not ride at an unsafe speed. Under no circumstance should you ride on roads with motor vehicles. The manufacturer recommends riders be 14+ years old. Always follow these safety instructions:
 - A. People who should not ride the Kick Scooter include:
 - i. Anyone under the influence of alcohol or drugs.
 - ii. Anyone who suffers from disease that puts them at risk if they engage in strenuous physical activity.
 - iii. Anyone who has problems with balance or with motor skills that would interfere with their ability to maintain balance.
 - iv. Anyone whose weight is outside the stated limits.
 - v. Pregnant women.
 - B. Riders under the age of 18 years old should ride under adult supervision.
 - C. Comply with local laws and regulations when riding this product. Do not ride where prohibited by local laws.
 - D. To ride safely, you must be able to clearly see what is in front of you and you must be clearly visible to others.
 - E. Do not ride in the snow, in the rain, or on roads which are wet, muddy, icy, or that are slippery for any reason. Do not ride over obstacles (sand, loose gravel, or sticks). Doing so could result in a loss of balance or traction and could cause a fall.
11. Do not attempt to charge your Kick Scooter if, the charger, or the power outlet is wet.
12. As with any electronic device, use a surge protector when charging to help protect your Kick Scooter from damage due to power surges and voltage spikes. Only use the original supplied charger. Do not use a charger from any other different product models.
13. Use only original parts and accessories. Do not modify your Kick Scooter. Modifications to your Kick Scooter could interfere with the operation of the Kick Scooter. could result in serious injury and/or damage, and could void the Limited Warranty.

2 Packing List

Assembled Kick Scooter



Accessories

Kick Stand



Power Cord



M5 Flathead Screw x 6



Hex Wrench x 2



Battery Charger




When unpacking your Kick Scooter, please verify that the above items are included in the package. If you are missing any components, please contact your dealer/distributor or nearest service center. After verifying that all components are present and in good condition, you can assemble your new Kick Scooter.


Please retain the box and packaging materials in case you need to ship your Kick Scooter in the future.

Remember to power off your Kick Scooter and unplug the power cord before assembling, mounting accessories, or cleaning the mainframe.

3 Diagram



Dashboard & Power Button




- Speedometer: Display the current speed of the KickScooter, as well as to display error codes.
- Modes: Three modes available. "ECO" for Energy saving mode (smooth acceleration, suitable for beginners). "D" for Standard mode and "S" for Sport mode (powerful, only recommended for skilled riders).
- Pedestrian mode: Makes pushing the KickScooter easier.
- Bluetooth: The icon indicates that the KickScooter has been successfully connected to the mobile device.
- Error: The wrench icon indicates that the KickScooter has detected an error.
- Battery Level: The battery power is indicated by 5 bars, each representing approximately 20% of a full battery.
- Power Button: Press the button to turn the KickScooter on; and press and hold the button for 3 seconds to turn the KickScooter off. When the KickScooter is on, press the button to turn the headlight on/off, and double press to switch between modes.

4 Assembling Your Kick Scooter


1. Unfold the handlebar stem and fasten it. Then unfold the kickstand to support the Kick Scooter.




2. Firmly connect the wires inside the handle and the stem. Slide the handle onto the stem. Be aware of the correct orientation.



4. Assemble the kick stand with the included hex wrench.



3. Install six screws (two on each side) with the included hex wrench.



5. Verify that your Kick Scooter can be powered on and off.



5 First Ride


There are safety risks when learning to ride the Kick Scooter. You must read the Riding Safety via the App before your first ride.

For your safety, your new Kick Scooter is not activated and will beep occasionally after Power ON.

Until activated, the Kick Scooter maintains very low riding speed, and cannot be ridden with full function. Install the App on your mobile device (with Bluetooth 4.0 or above), connect to the Kick Scooter with Bluetooth, and follow the App instructions to activate your Kick Scooter and enjoy the full performance.

Scan the QR code to download the App.

1 Install the App and register/login




2 Power on the Kick Scooter. A blinking Bluetooth icon indicates the Kick Scooter is waiting for a connection



3 Click "Vehicle"->"Scan for Vehicle" to connect to your Kick Scooter

The Kick Scooter will beep when the connection is successful. The Bluetooth icon will stop blinking and remain illuminated.



4 Follow the App instructions to activate the Kick Scooter and learn how to ride safely.

You can now start to use your Kick Scooter, check the status with App, Have fun!

6 Charging



Charging step tips

Open the charge port cover

Insert the charge plug

Close the charge port cover when finished

WARNING

Do not charge if the charge port or power cord is wet.

Do not charge or use your battery if it is damaged or see trace of water.

Close the charge port cover when not charging.

7 Learning to Ride




Wear an approved helmet and other protective gear to minimize any possible injury.



1. Power on the Scooter and check the power level indicator. Charge the Scooter if the battery level is low.




2. Stand on the footrest with one foot and push off with another foot to start gliding.




3. Put your other foot on the footrest to keep both feet stable. Press the throttle on the right hand to speed up when you are balanced.

Note, for your safety, the motor will not engage until the Kick Scooter reaches 1.86 mph (3 km/h).



4. Slow down by releasing the throttle; and brake by squeezing the brake lever.



5. To turn, Shift your body weight and turn the handle slightly.


WARNING

When hard braking, you risk serious injury due to loss of traction and falls. Maintain a moderate speed and look out for potential hazards .

8 Warnings



DO NOT ride the Kick Scooter in the rain.
DO NOT get wet.



Watch your head when
passing through
doorways

WARNING


Failure to follow these instructions could lead to serious injury.



DO NOT ride over speed bumps, thresholds, or
other bumps at HIGH SPEED




Do not keep your feet on the rear fender



DO NOT press the throttle when walking with the Kick Scooter




Avoid contacting obstacles with the tire/wheel




DO NOT Carry heavy objects on the handlebar



DO NOT ride the Kick Scooter with only one foot.




DO NOT ride on public roads, motorways, or highways.




DO NOT rotate the handle violently while driving at high speed.



DO NOT ride through puddles or other bodies of water.




The Kick Scooter is for one rider only. Do not carry any passengers. Do not carry a child. Do not ride when pregnant.



DO NOT touch the hub motor after riding because it can get hot.



DO NOT take e your hands off the handlebar while riding. Do not ride with one hand only.



DO NOT ride up and down stairs or Jump over obstacles.




DO NOT use mobile phone or earphones when operating the Kick Scooter.

WARNING

Always keep both hands on the handlebar or you risk serious injury due to loss of balance and falls.

9 Folding and Carrying



Turn off your Kick Scooter. Turn the safety hook counterclockwise and open the quick release lever

Align the snap hook and the buckle and hook them.

Disengage the snap hook from the buckle. Fold the handlebar stem up, close the quick release lever and turn the safety hook clockwise



When your Kick Scooter is folded up, lift it by the stem to carry.

10 Maintenance

Cleaning and Storage

Use a soft, wet cloth to wipe the mainframe clean. Dirt hard to remove can be scrubbed with a toothbrush and toothpaste, then cleaned with a soft, wet cloth.

NOTE

Do not wash your Kick Scooter with alcohol, gasoline, acetone, or other corrosive/volatile solvents. These substances may damage the appearance and internal structure of your Kick Scooter. Do not wash your Kick Scooter with a power washer or hose.

WARNING

Make sure the Kick Scooter is powered OFF, the power cord is unplugged, and the rubber cap on the charge port is tightly sealed before cleaning; otherwise you may damage the electronic components.

Store your Kick Scooter in a cool, dry place. Do not store it outdoors for extended periods of time. Exposure to sunlight and temperature extremes (both hot and cold) will accelerate the aging process of the plastic components and may reduce battery life.

Tire Pressure

Inflate tires to 32-37 psi. Inflate both tires equally.

Battery Pack Maintenance

Do not store or charge the battery at temperatures outside the stated limits (see Specifications). Do not puncture the battery. Refer to your local laws and regulations regarding battery recycling and/or disposal.

A well maintained battery can perform well even after many miles of riding. Charge the battery after each ride and avoid draining the battery completely. When used at room temperature (70°F [22°C]) the battery range and performance is at its best whereas using it at temperatures below 32°F (0°C) can decrease range and performance. Typically, at -4°F (-20°C) range can be half that of the same battery at 70°F (22°C). Battery range will recover when temperature rises.

NOTE

Typically, a fully charged battery should retain power for 120-180 days. A low-power battery should retain power for 30 - 60 days. Remember to charge the battery after each use. Completely draining the battery may cause permanent damage to the battery. Electronics inside the battery record the charge-discharge condition of the battery; damage caused by over-charging or under-charging will not be covered by the Limited Warranty.

WARNING

Do not attempt to disassemble the battery. Do not touch battery contacts. Do not dismantle or puncture the casing. Keep the battery contacts away from metal objects to prevent short circuit. Risk of fire and electric shock. No user serviceable parts. Do not charge or use your battery if it is damaged or see trace of water.

WARNING

Do not ride when the ambient temperature is outside the machine operation temperature (see Specifications) because low/high temperature will limit the maximum power/torque. Doing so could cause personal injury or property damage due to slips or falls.

11. Parameters

Basic parameter	
Product name	Electric scooter
Load	120kg
IP grade	IP54
Power performance	
Brake type	Electronic brake and physical brake
Cruising range	30-60km
Max speed	33km/h(⚡):8KM/H ECO:18KM/H D:28KM/H S:33KM/H
Maximum climbing angle	20-25degree
Other parameters	
Tires	10inch,solid tire ☐ , Inflatable tire ☐
Rated voltage	100-240VAC 50/60Hz
Motor/Power	Brushless motor/350W ☐ 500W ☐
Battery	36v ,7.8AH ☐ 10.4AH ☐ ,12.5AH ☐ ,15AH ☐
Charging time	5-7hours
Vehicle weight	20.9kg
Packing list	Electric scooter*1, user manual*1, screw*6,charging adapter*1, hexagon wrench*1

12. Warranty

I. Warranty service is carried out in accordance with the law on 《consumer rights》 and the 《Law on the quality of products.》 The warranty service includes

Recommendation: use the packaging for safe transport of the device. We recommend keeping the original packaging within 15 days after receipt of goods.

II. Warranty terms

Name	Information on warranty maintainance	Term
Main Unit	Frame,hub motor, controller, steering Wheel, handle bar, control panel, rear hub, brakes, disc brakes (folding) system, fork, front fork governance system bus control.brake cable	1 year
Accessories	Battery, power supply, brake level, switching gears	6 months
Exterior parts,that easily wear out	Anti-collision strip, headlights, instrument cover, handle sets, tires, inner tubes, bell, fender, taillights, ecorative cover, stand,battery compartment cover, foot pad, charging port, rubber stopper	3 months

Caution:

Hex wrench, connecting pipe and other consumable component parts have no warranty.

III. Non - warranty regulations

1. Authorized maintenance, misuse, collision, negligence, abuse, intake, accident. Improper use of non-product accessories, or tear up the modified label, anti-counterfeit mark.
- 2.The warranty period has expired;
- 3.Damage, caused by force majeure;
- 4.Failures, that have arisen in connection with the human factors (including, but not limited to, excessive wetting device, puncture, drop, scratch and damage an outer casing, which have arisen as a result of normal use of goods)
5. If this product is used for commercial purposes, all warranty conditions are not maintained.

